WARRANTY & CARE

2 Year Tent Guarantee

Please take time to read about the protection we offer you.

All our tents come with a guarantee designed to protect you as our valued customer. Flow Imports Ltd., the makers of ZEMPIRE® Camping Equipment tents, will repair or replace this tent, at their discretion, should it fail due to faulty materials or manufacture for a period of 2 years from the date of sale.

The Guarantee is subject to the following conditions:

- The Guarantee only applies to an original purchaser who purchased this tent from an approved retail outlet.
- The Guarantee does not apply if the tent has been used for anything other than reasonable personal camping use. Commercial use (e.g. rental) or continuous use as a residence are expressly excluded.
- 3. Damage due to normal wear and tear, accident, acts of God, negligence (other than by Flow Imports Ltd.), failure by the purchaser to ensure instructions for setting up and care are observed, deterioration due to abnormal exposure to ultraviolet light, insect or mildew attack, or any other cause reasonably beyond the control of Flow Imports Ltd. are not covered.
- 4. If redress is sought under the terms of this Guarantee, then the tent must be returned by the purchaser to the outlet from where it was purchased within the Guarantee period, in a clean, dry state and with proof of purchase.
- 5. All transport costs and any other indirect costs are excluded from the Guarantee.
- 6. Flow Imports Ltd. reserves the right to make a reasonable charge for repairs which it determines are not within the scope of the Guarantee.
- 7. The Guarantee does not limit, modify or exclude any rights under any law if doing so would contravene that law or make any part of this Guarantee invalid. However, Flow Imports Ltd.:
- a) excludes (to the extent permitted by applicable law) all conditions and warranties that might otherwise be implied; and
- b) limits its liability for breach of any such condition or Guarantee that it cannot exclude together with its liability under the Guarantee, to repairing or replacing the goods or paying the cost of having the goods repaired or replaced (at Flow Imports' option).

This tent has been made with meticulous care and attention to detail. Providing it's properly looked after and correctly stored, it will help you enjoy all that nature has to offer for years to come.

Care Instructions

- 1. Ensure guy ropes are out at all times during use.
- 2. Never pack your shelter away wet. If you must take your shelter down when wet, ensure that it is dried completely as soon as possible to prevent mildew forming.
- 3. If mildew does form on your shelter, wash off with warm water and a soft brush to prevent further growth, do not use soap or detergents.
- 4. Do not use an open flame inside your shelter. The fabric has been treated with a fire retardant but is in no way fire-proof.
- 5. Clean all pegs and poles before storing.
- 6. This shelter is not designed to withstand storm conditions. During strong winds, it is recommended that the shelter be taken down.
- 7. Do not leave your shelter pitched unnecessarily for extended periods of time, UV light damages the fly and will shorten the life of your shelter.

Get out more - you owe it to yourself!



PITCHING INSTRUCTIONS





ATTACHING THE WALL

Use the steps below for both the solid wall and mesh wall.

NOTE: Only one wall can be zipped on at a time.

- 1. Lay the wall out flat in front of your tent.
- 2. On the left side (facing the front of the tent) attach the zip end through both zipper sliders on the tent.
- 3. Pull the zipper closed, lifting the wall as you go to reduce tension on the zipper.
- 4. Peg out the front corners of the wall so that the panels are evenly tensioned.

NOTE: To make the front door easier to access, the "anchor webbing Y-strap" can be converted to a single strap. To do this, unclip the outer buckle on the Y-strap and secure the outer side using the clip located below the inner side's buckle. You may need to adjust the angle and tension of the anchor webbing to suit this single strap configuration.



WARNING

KEEP ALL FLAME AND HEAT SOURCES AWAY FROM THIS TENT FABRIC

USING THE SOLID WALL AS AN AWNING

It is possible to attach the solid wall as an awning to provide additional shade and shelter. This is possible with or without the mesh wall attached (see front page).

- 1. First attach the buckles at the top of your Awning Wall to the corresponding buckles on the front of the tent found between the front tube and awning valance.
- 2. Remove the two "anchor webbing Y-straps" from the front of the tent.
- 3. Attach each anchor webbing strap to the corresponding buckles on the bottom of your wall. To convert your Y-strap to a single anchor strap, you will need to secure one side of the Y-strap to the clip located below the inner side's buckle.

4. Assemble the awning poles:

EVO TXL Wall Poles = 2×3 Long Sections, 1×4 Short Sections EVO TL & TM Wall Poles = 2×3 Long Sections

- 5. Insert an awning pole through each eyelet on the awning wall.
- 6. Peg out and adjust the webbing straps to tension the wall/awning.

NOTE: For extra shelter, attach a guy rope to the steel ring on each side of the awning wall and tension. The TXL Wall will also require an additional guy rope for the center awning pole.

Condensation

It is important that lower vents are opened at all times to reduce the risk of condensation. During humid or damp conditions, it is recommended that the waterproof door covers are opened to expose the mesh layer, enabling additional airflow throughout your tent.

Do not use foam swabs or non-bonded mats directly on the tent floor. This will cause condensation between the mat and floor and if not dried out, can lead to mildew forming.



Please turn page for Care Instructions and Warranty.

For a detailed description of all the features and specifications of this product please visit our website.